


WRITE-AND-ERASE SOUND BOOK

Learn to write ABCs or 123s! Hear, see, and write letters or numbers, then wipe the pages clean and play again!


Book-and-pen set develops foundational writing, reading, and/or math skills

Audio reinforces letter or number recognition

Using a marker builds fine motor skills



**Mickey Mouse Clubhouse:
Count to 10**
ISBN 978-1-6055-3568-5
ITEM# 7503600



**Mickey Mouse Clubhouse:
Let's Write the Alphabet**
ISBN 978-1-5037-1690-2
ITEM# 7767400



PAW Patrol: ABCs
ISBN 978-1-5037-1691-9
ITEM# 7767500

11" x 11.75"

Board book with write-and-erase pages

8 content spreads

Write-and-erase marker

28 sound buttons

3 replaceable 357/AG13/LR44 button cell batteries included